



INSTRUCTIONS FOR CARE OF COMPOSITE SINK

The composite surface is durable, hygienic and easy to clean. You can keep it clean and beautiful by following the instructions below.

1. After using the sink, always wipe any spots or stains from the sink surface with a washcloth or sponge. For cleaning, use hot water and washing-up liquid. Then rinse the surface with clean water and dry it with a soft cloth. It is recommended to remove stains and marks as soon as possible, so they will not stick into the surface of the sink.

2. Water that remains on the sink surface may cause grey lime marks on drying. Clean the sink using washing-up liquid, then rinse and dry it. Discoloration can be avoided by always drying the sink surface after use.

3. Scouring powders or steel wool will scratch the sink – DO NOT USE THEM. Do not leave a wet cast-iron or other non-rustproof metal container on the sink for a long time, because these might leave a mark on the surface.

4. Stubborn dirt can best be removed by using Stala cleaning sponge: Moisten the sponge with clean water and rub off the marks or stains. Do not use other detergents.

5. Stains of lime, coffee or tea can be removed with a deliming agent. The sink must be rinsed properly afterwards. It is recommended to do the deliming once a month or when necessary.

Composite surfaces will not be affected by dry heat up to 280°C. Kitchen equipment could heat up to higher temperature than this, so we recommend to use heat resistance silicone mats or similar to protect the surface.

RECYCLING OF COMPOSITE SINK

Composite sink is quartz based material, please recycle it with mixed waste. Siphons can be recycled with plastic waste and metallic waste.

TIPS FOR VEDLIKEHOLD AV KOMPOSITTVASKER

Overflaten av en komposittvask er slitesterk og hygienisk. Den kan holdes ren og pen ved hjelp av følgende vedlikeholdstips.

1. Tørk alltid bort flekker med et mykt kjøkkenhåndkle, en klut eller en svamp når du er ferdig med arbeidet. Bruk varmt vann, svamp og flytende oppvaskmiddel for å rengjøre overflaten. Skyll deretter med rent vann og tørk av med en myk klut. **OBS!** Flekker og søl bør rengjøres så snart de oppstår, slik at smusset ikke rekker å feste seg på overflaten.

2. Vann som blir liggende på vaskens overflate, kan etterlate gråhvite flekker av kalkavleiringer når det tørker. Rengjør vasken med flytende oppvaskmiddel, skyll og tørk av. Unngå misfargende flekker ved å tørke av vasken etter bruk.

3. Skurepulver, stålull og vaskemiddel som inneholder slipemidler, kan lage riper i overflaten. La heller ikke våte gryter av jern eller et annet rustende materiale bli stående på benken i lengre tid, da de etterlater seg spor på overflaten.

4. Inngrødd smuss fjernes best ved kraftig rengjøring av vasken med en flekkfjerningssvamp (f.eks. Stala/ICA). Rengjør overflaten ved å gni den med svampen. Ikke bruk andre oppvask- eller skuremidler.

5. Flekker av kalk, kaffe og te fjernes med avkalkingsmiddel. Etter avkalkingen skal vasken skyllses grundig. Vi anbefaler avkalking en gang i måneden eller ved behov.

Komposittvaskens overflate tåler varme på opptil 280 °C uten problemer. Kjøkkenredskaper kan imidlertid være varmere enn dette. Derfor anbefaler vi at du bruker egnede underlag på vasken.

GJENVINNING AV KOMPOSITTVASKEN

Komposittvasken er laget av kvarts. Gjenvinn vasken som blandet avfall. Vannlåsen kan sorteres som plast- eller energiavfall og som metallavfall.